


2. Find button at top of immersion and press (this is a delicate switch so you may not feel it click). Once this is done, turn the EDDI back on to see if issue is resolved.



3. If issue continues,
POWER OFF THE EDDI
COMPLETELY (see step 1.)
and remove the top
cover by unscrewing the
nut. Once removed,
reset the limit switch by
pushing down with a
pen on the button – this
will not click, it is a very
small area.



4. Thermostat gauge must then be turned down – twist gauge to 50 degrees. Screw the top cover back on and power EDDI back up to see if issue is resolved. If this issue continues, please contact the office directly.

